

模式切换	按 键		⑨ 舞蹈运控	R1 + B	
零力矩	L2 + Y	★	L 查尔斯顿舞 1(→1m)	R1 +	★
① 阻尼	L2 + B	★	L 查尔斯顿舞 2(↑1m,←1m)	R1 +	★
② 锁定站立	L2 +	★	L 查尔斯顿舞 3(↗3m)	R1 +	★
⑤ 躺 -> 站	L2 + X	★	L 截拳道 (3m*3m)	R2 +	★
④ 落座	L2 +	▲	L 扭扭舞 (3m*3m)	R2 +	★
⑥ 蹲 <-> 站	L2 + A	▲	交互功能	按 键	
⑩ 自适应起身	R1 + R2 + X	★	L 握手	+ A	★
运控切换	按 键		L 高举挥手	+ Y	★
③ 走跑运控	R2 + A	▲	L 胸前挥手	双击 Y	★
L 低速 / 高速	R2 + ( / )	★	L 飞吻	双击 X	★
⑦ 常规运控	R1 + X	▲	L 鼓掌	双击 A	★
L 低速 / 高速	双击 L2 / L1	★	I. ★ 代表短按一次生效, ▲ 代表长按 2 秒生效 II. 运控状态下长按 5 秒 ①, 设备进入阻尼保护状态 III. 躺倒开机: 开机-①-⑩-演示-⑥-关机 IV. 蹲姿开机: 开机-①-⑥-演示-⑥-关机 V. 座椅开机(推荐): 开机-①-②-③-演示-④-关机 (Tips: ② - ③过程需要人扶直站立) VI. 舞蹈或上肢动作时, 双击  可紧急中断舞蹈 VII. 括号内注明了舞蹈所需的活动空间		
⑧ 越障运控	R2 + B	▲			
L 踏步 / 站立	双击	★			
语音模式切换	按 键				
常规/迎宾	R1 + R2 + Y	★			

Mode	Button		⑨ Dance Mode	R1 + B	
Zero Moment	L2 + Y	★	L Charleston dance1 (→1m)	R1 +	★
① Damping	L2 + B	★	L Charleston dance2 (↑1m,←1m)	R1 +	★
② Locked Standing	L2 +	★	L Charleston dance3 (↗3m)	R1 +	★
⑤ Lie -> Stand	L2 + X	★	L Jeet Kune Do(3m*3m)	R2 +	★
④ Seated Mode	L2 +	▲	L Twist(3m*3m)	R2 +	★
⑥ Squat <-> Stand	L2 + A	▲	Interactional	Button	
⑩ Adapt Rise	R1 + R2 + X	★	L Handshake	SELECT + A	★
<b>Motion Control Switching</b>	<b>Button</b>		L Wave Hand	SELECT + Y	★
③ Running Mode	R2 + A	▲	L Face Wave	Double Click Y	★
L Low/High Speed	R2 + (  /  )	★	L Right Kiss	Double Click X	★
Regular Mode	R1 + X	▲	L Clap	Double Click A	★
L Low/High Speed	Double Click L2 / L1	★	I. ★ a single short press to activate ▲ a long press for 2 seconds to activate II. In motion control mode, long-pressing button ⑩ for 5 seconds entering damping protection mode III. Lie down and turn on: Turn On - ① - ⑩ - Demo - ⑩ - Turn off IV. Squat position turn on: Turn On - ① - ⑥ - Demo - ⑥ - Turn off V. Seat power on (recommended): Turn On - ① - ② - ③ - Demo - ④ - Turn off (Tips: ② and ③ require manual assistance to help the robot stand upright) VI. Double Click  to emergency-stop the dance during upper-body motions. VII. Parentheses show the required dance space		
⑧ Climb Mode	R2 + B	▲			
L Stepping/Standing	Double Click	★			
<b>Switch to Voice Mode</b>	<b>Button</b>				
Normal / Welcome	R1 + R2 + Y	★			