



Mode	Button
Zero Moment Mode	Hold L1 + Click B
Damping Mode ①	Hold L1 + Click A
Locked Standing ②	Hold L1 + Click 
Seated Mode ④	Hold L1 + Click 
Lie → Stand ⑤	Hold L1 + Click X
Squat ←→ Stand ⑥	Hold L1 + Click Y

Mode	Button
Wave Hand	Hold SELECT + Click Y
Handshake	Hold SELECT + Click A
Turn Around and Wave Hand	Hold SELECT + Click X

Mode	Button
1-Dof-Waist ③	Hold R1 + Click X
Keep Stepping	Double Click START
Standing	Click START
Low Speed Mode	Double Click L2
High Speed Mode	Double Click L1

Mode	Button
3-Dof-Waist ③	Hold R1 + Click Y
Keep Stepping	Double Click START
Standing	Click START
Low Speed Mode	Double Click L2
High Speed Mode	Double Click L1

Lie down and turn on:

Turn On -> ① -> ⑤ -> Show -> ⑥ -> turn Off

Squat position turn on :

Turn On -> ① -> ⑥ -> Show -> ⑥ -> turn Off

Seat power on (recommended):

Turn On -> ① -> ② -> ③ -> Show -> ④ -> Turn Off



※Tip: When the seat is turned on, ②-③ processes require a person to stand upright